



RINZA[®] MILK SYSTEM CLEANING

THE TRUTH::

1. Milk fats, solids and collect on the outside and inside of of steam wands and milk systems..
2. Bacteria growth can cause food borne illness.

THE SOLUTION:

1. Wipe the steam wand after each use with a wet cloth.
2. Daily clean steam wands and milk systems to prevent bacteria growth.



INSTRUCTIONS FOR DAILY USE

STEAM WANDS

1. Mix one (1) Rinza M61 tablet per 8oz / 250 ml water.
OR
Mix 25ml Rinza per 8oz / 250 ml water.
2. Heat with steam wand and allow solution to back syphon into steam wand.
3. Soak parts or steam wand for 15-30 minutes in solution.
3. Rinse all components.

For steam wands



INSTRUCTIONS FOR DAILY USE

AUTOMATIC MILK FROTHER

1. Mix one (1) Rinza M61 tablet per 8oz / 250 ml water.
OR
Mix 25ml Rinza per 8oz / 250 ml water.
2. Insert suction tube into solution. Run entire solution through frother.
3. Repeat above with clean cold water to thoroughly rinse all components.

